

Britax B2



Contents

1. Suitability	1
2. Folding the pushchair	2
3. Assembling the pushchair	3
4. Using the pushchair	4
4.1 Using the brakes	4
4.2 Applying and adjusting the harness	4
4.3 Adjusting the backrest	5
4.4 Adjusting the leg support	5
4.5 Adjusting the swivel wheels	5
4.6 Varying the hood	6
5. Use with the infant carrier - Travel System	6
5.1 Fitting the infant carrier	6
5.2 Removing the infant carrier	7
6. Care instructions	7
6.1 Cleaning	8
7. 2-year warranty	8
8. Warranty Card / Transfer Check ..	9

User instruction

We are pleased that our **B2** will accompany your child safely through the first years of his or her life.



A child's safety is your responsibility

- Read these instructions carefully and make yourself familiar with the pushchair before using it with your child.
- If your pushchair is used by someone unfamiliar with it (for example grandparents) always show them how the pushchair works.
- Your child's safety may be affected if you do not follow these instructions.
- Keep this user instruction in a safe place for future reference.

If you have any further questions regarding its use, please feel free to contact us.

BRITAX RÖMER
Kindersicherheit GmbH

1. Suitability



For the protection of your child

WARNING! This pushchair is **not** suitable...

- ... for the transport of children under 6 months in the pushchair seat.
- ... as a substitute for a cot or a cradle.
Carrycots, prams and buggies may be used only for transporting babies or children.
- ... for jogging, running, skating or similar activities.
Using a pram or buggy for another than its typical purpose can be dangerous.
- ... for the transport of more than one child.
- ... for commercial use.
- ... as a Travel System in connection with other infant carriers.

This pushchair is suitable...

This pushchair is designed and manufactured to comply to the following Standard EN1888:2005-11.



... as a Travel System with the infant carrier:

- from birth to 13 kg.

The **Visio** can be used as a travel system with all RÖMER infant carriers which are equipped with the "**Type A**" adapter.



... as a buggy in the pushchair seat:



- from 6 months to 15 kg.

2. Folding the pushchair



For the protection of your child

- **WARNING!** Make sure that all locks are properly latched prior to every use.
- Make sure that no locks disengage accidentally while the pushchair is carried.




- When folding the pushchair make sure that you do not pinch any part of yourself or others.
- Never fold the pushchair when it is occupied by a child.


This is how to unfold the pushchair:

- ✎ Undo the locking hook **1** and pull the upper part of the pushchair upwards by the handles **2**.

- ✎ Pull the handles **2** towards you and hold the pushchair with your foot placed on the knob **3** of the rear X-brace.



- ✎ Press the knob **3** on the rear X-brace downwards with your foot. **Caution!** Ensure the rear X-brace is fully engaged.



This is how to fold the pushchair:

Tip! The pushchair can be folded more comfortable if the brakes **13** are released (see 4.1), the canopy **11** is folded back and the swivel wheels **5** are locked (see 4.5).

- ✎ Push the knob **3** on the rear X-bracing upwards.




- ✎ Push the safety button **4** on the right side downwards with the foot. Now the folding mechanism is unlocked.

D



- ✎ Push the handles **2** as far forward as possible.
The pushchair folds.

1



- ✎ Close the locking hook **1**.

3. Assembling the pushchair


This is how to assemble the wheels:

- ✎ Lay the pushchair back with its handles **2** to the floor.
- ✎ Push the two swivel wheels **5** onto the end of the front legs **6**.
- ✎ Press down the swivel wheels **5** on the front legs **6** until they engage.
- ✎ Repeat this with the other wheels.


Caution! Pull on the wheels to check if they engaged properly.

To take off the wheels:

- ✎ Lay the pushchair back with the push handles **2** on the floor.
- ✎ Press on the locking tab **40** and pull the swivel wheels **5** from the front legs **6**.




D




How to mount the safety bar **9:**

- ✎ Slide the ends of the safety bar **9** into the recesses **10** in the armrests **8** until the locking button **7** engages.




To take off the safety bar **9:**

- ✎ Press from below on the locking button **7** and pull out the safety bar **9** from the recess **10**.



How to fasten the hood **11:**

- ✎ Clip the hood clips **12** above the armrests **8** onto the frame tube.
- ✎ Press both hood tensioners **13** downwards.
- ✎ Fasten the Velcro fasteners on the side of the seat cover.



How to take off the hood **11:**

- ✎ Undo the Velcro fasteners.
- ✎ Pull the hood clip **12** upwards at the recessed grip.
The hood **11** disengages.


4. Using the pushchair



For the protection of your child

- **WARNING!** Always secure your child in the pushchair using the harness.
- **WARNING!** Never leave your child unattended in the pushchair, even for a short time.
- Always put the brakes on when parking the pushchair and before letting go of it.
- Always avoid parking on slopes.
- Support the back of the pushchair seat when reclining it.
- Make sure that your child is clear of moveable parts when re-adjusting the pushchair.
- Do not allow your child to play with or adjust the pushchair.
- Do not allow your child to stand or ride in the shopping basket.
- **WARNING!** Do not hang shopping or other heavy objects on the handles. This can make the pushchair unstable.
- Take special care to ensure the pushchair stands firmly and safely when using public transport.

14




4.1 Using the brakes

This is how to engage the brakes:

- ✎ Push down on the end of the brake bar 14 with your toes.


Caution! Always check if the brakes have engaged firmly before letting go of the pushchair.

14



17

16



This is how to release the brakes:

- ✎ Push upwards on an end of the brake bar 14 with your toes.

4.2 Applying and adjusting the harness



A correctly adjusted 5-point harness gives your child the necessary support in the pushchair.

Tip! If using an alternative harness conforming to BS6684, D ring attachments are found on each side of the pushchair.




For the protection of your child

- **WARNING!** Always use a correctly fitted and adjusted harness.
- **WARNING!** Always use the crotch strap in connection with lap belt part.

This is how to secure your child using the harness:

- ✎ Push the buckle prongs 16 on either side through the slots in the shoulder straps 17.



☞ Engage both buckle prongs **16** in the buckle housing **18** with an audible **CLICK**.


☞ Adjust the harness by pulling the slider **19** until the desired fit is achieved.

Tip! All straps can be adjusted separately.

Caution! Always re-adjust the harness when changing the seating position of your child.

This is how to open the harness:

☞ Squeeze the top and bottom prongs **16** at the buckle housing **18**.



4.3 Adjusting the backrest





This is how to adjust the backrest to one of 4 positions:


☞ Hold the backrest **20** with one hand.

☞ Pull upwards the backrest adjustment handle **21** with the other hand.

☞ Move the backrest **20** upwards or downwards until it locks into the desired position.



23



23

22

4.4 Adjusting the leg support



This is how to put the leg support **23 up:**

☞ Swing the leg support **23** upwards into the desired position.

This is how to put the leg support **23 down:**


☞ Press the regulating buttons **22** on both sides.

☞ Adjust the leg support **23** to the desired position.

4.5 Adjusting the swivel wheels

This is how to adjust the swivel wheels **5 pivoted:**

☞ Push the clips **24** down.




5

24

This is how to lock the swivel wheels **5:**


☞ Align both swivel wheels **5** to rear of the front leg.

☞ Push the clips **24** upwards.



5

24



4.6 Varying the hood

Opening the hood window 34

- ✎ Open the Velcro fastener.
- ✎ Roll up the cover 35 and fasten it with the retaining strap.

5. Use with the infant carrier - Travel System




The **B2** can be used as a travel system with all RÖMER infant carriers which are equipped with the "**Type A**" adapter. It is simply clipped from underneath into the edge of the infant carrier.



For the protection of your child


- **WARNING!** Make sure that the infant carrier is safely connected with the pushchair.
- Never grasp at the infant carrier to lift or push the pushchair.
- Always engage the brake before fitting the infant carrier onto the pushchair or removing it.




5.1 Fitting the infant carrier




- ✎ Engage the brake 14 (see 4.1).
- ✎ Move the backrest 20 of the pushchair seat to the lie flat position (see 4.3).



- ✎ Unhook the cover at the armrests 8. You can now see the locating slots 26 in the armrests 8.
- ✎ Fold the cover to the seating surface.



- ✎ Lower the infant carrier on the pushchair rearward facing. **Caution!** Never try to fix the infant carrier on the pushchair forward facing.





- ✎ Engage the fixation prongs 28 of the infant carrier into the fixation slots 26 either side. **Caution!** Make sure that the infant carrier is safely connected with the pushchair.
- ✎ Lower the infant carrier handle to the rocking position.

5.2 Removing the infant carrier



- ✎ Engage the brake **14** (see 4.1).
 - ✎ Return the infant carrier handle to the carrying position.
 - ✎ Push up the release button **29** on both sides of the infant carrier.
 - ✎ Lift the infant carrier until the fixation prongs **28** release from the fixation slots **26**.
- Caution!** Firmly hold the infant carrier when lifting.



- ✎ Now you can lift off the infant carrier from the pushchair.
- ✎ Hook the cover in place at the armrests **8**.

6. Care instructions



To retain the safe function

- Regularly check all important parts for damage. Ensure the correct operation of all mechanical components.
- The pushchair can be damaged or destroyed by overloading, improper folding or use of unapproved accessories.
- Never use other spare parts or accessories than those supplied or approved by the manufacturer.
- Keep your nursery product clean.
- Do not allow the pushchair to remain wet for prolonged periods of time. If it does get wet, allow to dry unfolded at room temperature.
- Never place heavy objects on the hood.
- Do not carry more than 3 kg in the shopping basket.

Store the pushchair in a safe place when it is not in use:

- Avoid placing heavy objects on top of it.
- Do not store it near a direct heat source, e.g. radiators.
- Do not store it in direct sunlight. The cover may fade.
- Do not store the product folded in damp or wet climates. Always store it unfolded in a well ventilated area to avoid mildew.

This is how you can remedy minor defects yourself:

If the **wheels** squeak:

- ✎ Use a silicon based spray or light oil ensuring it penetrates the wheel and axle assembly.

When using your pushchair **at the beach**:

- ✎ Completely clean your pushchair afterwards to remove the sand and salt from the mechanisms and wheel assemblies.

If there are **compressions** on the tyres:

- ✎ Use a domestic hair dryer to gently warm the tyre. The compression marks should slowly disappear.
- Caution!** Do not overheat!

If **fasteners** become loose:

- ✎ Promptly tighten screws and nuts using appropriate tools.

If **parts** become bent, torn or broken:

- ✎ Promptly exchange the parts. Use only those parts and accessories approved by Britax.

6.1 Cleaning

- The **seat cover** cannot be removed. Clean the **seat cover** and the **canopy** with a sponge and luke warm soapy water. Please observe the washing instructions on the label. Allow the parts to dry fully, preferably away from direct sunlight.
- The **plastic parts** and the **metal parts** can be cleaned with a damp cloth. After contact with water the metal parts should be wiped off to avoid rust.

This is how you can remove the shopping basket 30 for cleaning:

- 🔧 Open the push buttons on the retaining straps **31**.



7. 2-year warranty

For this car/bicycle child seat / pushchair we provide a 2-year warranty against manufacturing or material defects. The warranty period is effective from the day of purchase. As proof we ask that you fill out the Warranty Card and retain it for the whole term of the warranty period, together with the Transfer Check signed by you and your sales receipt. In the case of a warranty claim, the Warranty Card must be returned together with the product. The Warranty covers only car/bicycle child seats / pushchair which have been handled properly and which have been sent to us in a clean condition.

The Warranty does not cover:

- natural signs of wear and damage resulting from excessive stress.
- damage resulting from inappropriate or improper use.

What is covered by the Warranty?

Fabric: All our materials meet very high requirements with regard to colour fastness when exposed to UV radiation. Nevertheless, all fabrics fade when exposed to UV radiation. This is not a material defect, but rather a normal sign of wear which is not covered by the Warranty.

Buckle: Buckle malfunction is often due to accumulations of dirt and dust which may stop it from working properly. If this happens, the buckle can be washed out. Please refer to your user instructions.

Please contact your retailer directly in the event of a warranty claim. He or she will give you the advice and support you need. When processing claims, product-specific depreciation rates will be applied. Please refer to our General Terms and Conditions which are available from your retailer.

Use, care and maintenance

The car/bicycle child seat / pushchair must be used in accordance with the user instructions. We would like to point out that it is extremely important that only Britax accessories and replacement parts are used.

8. Warranty Card / Transfer Check

Name: _____

Address: _____

Post Code: _____

City/Town: _____

Telephone No.
(including area code): _____

e-mail address: _____

Car/bicycle child seat
/ pushchair: _____

Article No.: _____

Fabric colour
(design): _____

Accessories: _____

Date of purchase: _____

Buyer (signature): _____

Retailer: _____

Transfer Check:

1. Completeness

☐ examined
OK

☐ I have checked the child car/
bicycle seat / pushchair and am
sure that the seat was complete
on delivery and that all functions
are sound.

2. Function test

- Seat adjustment
mechanism

☐ examined
OK

- Harness adjustment

☐ examined
OK

☐ I received adequate information
on the product and its functions
prior to purchase and have
noted the care and maintenance
instructions.

3. Intactness

- Seat

☐ examined
OK

- Fabrics

☐ examined
OK

- Plastic parts

☐ examined
OK

Retailer's stamp